

AMI-II Deltacon Power

Operator's Manual



MADE IN
SWITZERLAND



AMI-II Deltacon Power



Customer Support

Swan and its representatives maintain a fully trained staff of technical specialists around the world. For any technical question, contact your nearest Swan representative, or the manufacturer:

Swan Analytische Instrumente AG
Studbachstrasse 13
8340 Hinwil
Switzerland

Internet: www.swan.ch
E-mail: support@swan.ch

Document Information

Title: AMI-II Deltacon Power Operator's Manual
ID: A-96.210.451
Revision: 00.00, 2026-06-02

History of Major Document Revisions

Revision	Issue	Description
00.xx	June 2026	First edition

Table of Contents

1. Safety Instructions	3
1.1. Warning Notices	4
1.2. General Safety Regulations	6
1.3. Restrictions for Use	7
2. Product Description	8
2.1. Description of the System	8
2.2. Instrument Specification	14
2.3. Instrument Overview	16
2.4. Single Components	17
2.4.1 AMI-II Transmitter	17
2.4.2 Swansensor UP-CON1000 SL	18
2.4.3 Flow Cell CATCON+ SL	19
3. Installation	20
3.1. Installation Checklist	20
3.2. Mounting the Instrument	21
3.3. Connecting Sample Inlet and Outlet	22
3.3.1 Stainless Steel Swagelok Fitting at Sample Inlet	22
3.3.2 FEP Tube at Sample Outlet	23
3.4. Installation of Cation Exchanger	24
3.5. Electrical Connections	25
3.5.1 Connection Diagram	26
3.5.2 Power Supply	27
3.6. Relay Contacts	28
3.6.1 Input	28
3.6.2 Alarm Relay	28
3.6.3 Relay 1 and 2	28
3.6.4 Types of Loads	29
3.7. Signal Outputs	29
3.7.1 Signal Output 1 and 2 (Current Outputs)	29
3.8. Interface Options	30
3.8.1 Signal Outputs 3 and 4	31
3.8.2 RS485 (Profibus or Modbus Protocol)	31
3.8.3 HART	32
4. Instrument Setup	33
4.1. Establish Sample Flow	33
4.2. Programming	34

5. Operation 35

5.1. Keys 35

5.2. Display 36

5.3. Software Structure 38

5.4. Changing Parameters and Values 39

6. Maintenance 40

6.1. Maintenance Schedule 40

6.2. Stop of Operation for Maintenance 40

6.3. Maintenance of the Sensor 41

6.3.1 Remove the Sensor from the Flow Cell 41

6.3.2 Install the Sensor into the Flow Cell 41

6.4. Changing the Cation Exchanger 42

6.5. Changing the Inlet Filter 46

6.6. Tube Connections 47

6.7. Replace the Deaeration Tubes 48

6.7.1 Exchange Deaeration Tube of Cation Exchanger Bottle 49

6.7.2 Exchange Deaeration Tube of Pre-Rinse Bottle 49

6.8. Quality Assurance of the Instrument 50

6.9. Longer Stop of Operation 53

7. Troubleshooting 54

7.1. Error List 55

7.2. Replacing Fuses 58

8. Program Overview 59

8.1. Messages (Main Menu 1) 59

8.2. Diagnostics (Main Menu 2) 60

8.3. Maintenance (Main Menu 3) 61

8.4. Operation (Main Menu 4) 62

8.5. Installation (Main Menu 5) 64

9. Program List and Explanations 66

10. Material Safety Data sheets 86

10.1. Swan Cation Exchange Resin 86

11. Default Values 87

Operator's Manual

This document describes the main steps for instrument setup, operation and maintenance.

1. Safety Instructions

General	The instructions included in this section explain the potential risks associated with instrument operation and provide important safety practices designed to minimize these risks. If you carefully follow the information contained in this section, you can protect yourself from hazards and create a safer work environment. More safety instructions are given throughout this manual, at the respective locations where observation is most important. Strictly follow all safety instructions in this publication.
Target audience	Operator: Qualified person who uses the equipment for its intended purpose. Instrument operation requires thorough knowledge of applications, instrument functions and software program as well as all applicable safety rules and regulations.
OM location	Keep the Operator's Manual in proximity of the instrument.
Qualification, training	To be qualified for instrument installation and operation, you must ♦ read and understand the instructions in this manual as well as the Material Safety Data Sheets, ♦ know the relevant safety rules and regulations.

1.1. Warning Notices

The symbols used for safety-related notices have the following meaning:



DANGER

Your life or physical wellbeing are in serious danger if such warnings are ignored.

- ♦ Follow the prevention instructions carefully.



WARNING

Severe injuries or damage to the equipment can occur if such warnings are ignored.

- ♦ Follow the prevention instructions carefully.



CAUTION

Damage to the equipment, minor injury, malfunctions or incorrect process values can be the consequence if such warnings are ignored.

- ♦ Follow the prevention instructions carefully.

Mandatory signs

The mandatory signs in this manual have the following meaning:



Safety goggles



Safety gloves

Warning signs The warning signs in this manual have the following meaning:



Electrical shock hazard



Corrosive



Harmful to health



Flammable



General warning



Attention



1.2. General Safety Regulations

Legal requirements

The user is responsible for proper system operation. All precautions must be followed to ensure safe operation of the instrument.

Spare parts and disposables

Use only official Swan spare parts and disposables. If other parts are used during the normal warranty period, the manufacturer's warranty is voided.

Modifications

Modifications and instrument upgrades shall only be carried out by an authorized service technician. Swan will not accept responsibility for any claim resulting from unauthorized modification or alteration.



WARNING

Electrical shock hazard

If proper operation is no longer possible, the instrument must be disconnected from all power lines, and measures must be taken to prevent inadvertent operation.

- ♦ To prevent from electrical shock, always make sure that the ground wire is connected.
- ♦ Service shall be performed by authorized personnel only.
- ♦ Whenever electronic service is required, disconnect instrument power and power of devices connected to
 - relay 1,
 - relay 2,
 - alarm relay.



WARNING

For safe instrument installation and operation you must read and understand the instructions in this manual.

1.3. Restrictions for Use

The AMI-II Deltacon Power is designed for determination of:

- ♦ specific (total) conductivity
- ♦ cation (acid) conductivity after a cation exchanger

in power and industrial plant water.

It calculates the pH value and the concentration of an alkaline substance (NH₃, morpholine, etc.) if present in the water.

It is not suitable for pH determination in high purity water before alkalization agent addition.

Conditions for pH calculation:

- ♦ Only one alkalization agent (acid-base pair) in the sample. No mixture.
- ♦ The contamination is mostly NaCl.
- ♦ Phosphate concentration is <0.5 ppm.
- ♦ pH value is >7.5, and <10.5.
- ♦ If pH value is <8, the concentration of contaminant must be small compared to the concentration of the alkalization agent.

No sand. No oil.

The sample must not contain any particles which may block the flow cell. Sufficient sample flow is coercive for the correct function of the instrument.



2. Product Description

2.1. Description of the System

Application range	The AMI-II Deltacon Power is a complete monitoring system for the automatic, continuous measurement of the conductivity before (specific conductivity) and after a cation exchanger (cationic or acid conductivity). Based on difference conductivity measurement, the pH and the alkalinizing agent concentration of the sample can be calculated.
Available models	The instrument is available in two variants: ♦ Monitor on stainless steel panel. ♦ Single components.
Special features	♦ Temperature compensation curves for specific conductivity measurement: – Strong acids (HCl) – Strong bases (NaOH) – Ammonia – Morpholine – Ethanolamine (ETA) – Cyclohexylamine (CHA) – 2-Amino-2-methylpropanol (AMP) – 2-Diethylaminoethanol (DEAE) – Hydrofluoric acid ♦ Flow monitoring ♦ Monitoring of resin exhaustion ♦ Calculation of pH according to VGBE-S-010-00-2023-08 ♦ Calculates the concentration of an alkalizing agent present in the water
Signal outputs	Two signal outputs programmable for measured values (freely scalable, linear, bilinear, log) or as continuous control output (control parameters programmable). Current loop: 0/4–20 mA Maximal burden: 510 Ω Two additional signal outputs with the same specifications available as an option.


Alarm relay	Two potential-free contacts (one normally open and one normally closed contact). Summary alarm indication for programmable alarm values and instrument faults. ♦ Normally open contact: Closed during normal operation, open on error and loss of power. ♦ Normally closed contact: Open during normal operation, closed on error and loss of power. Maximum load: 1 A/250 VAC
Relays	Two potential-free contacts programmable as limit switches for measured values, controllers or timers with automatic hold function. Maximum load: 1 A/250 VAC
Input	One input for potential-free contact to freeze the measured value or to interrupt control in automated installations. Programmable as HOLD or OFF function.
Communication interface (optional)	♦ Two additional signal outputs ♦ RS485 with fieldbus protocol Modbus RTU or Profibus DP ♦ HART
Safety features	No data loss after power failure. All data is saved in non-volatile memory. Overvoltage protection of inputs and outputs. Galvanic separation of measuring inputs from signal outputs.

Fluidics The sample enters the flow cell block [B] through the sample inlet [G] and the flow regulating valve [C]. With the first conductivity sensor [A] the specific conductivity of the sample is measured. The sample then passes through the cation exchanger bottle [M], where the alkalinizing agent is removed. Downstream the cation exchanger, cation conductivity is measured by the second conductivity sensor [H]. The sample leaves the measuring cell via the flow meter [I] and the sample collector [J] and flows to the pressure-free sample outlet [N]. The sample temperature is measured by the temperature sensor integrated in the conductivity sensor.

Pre-rinse option AMI-II Deltacon Power with pre-rinse option allows for an immediate resin change without additional rinse time, as the resin is pre-rinsed in a separate bottle. Pre-rinsing removes impurities from the resin that otherwise interfere with the measurement.

If the pre rinse option is installed, the sample flows from the flow meter through the pre rinse inlet [D] into the second cation exchanger bottle [F]. From there, the sample flows via the pre rinse outlet [E] through the sample collector [J] into the waste funnel.

The cation exchanger bottles are automatically vented via two small tubes connected to the sample collector at [K] and [L].



- | | |
|-------------------------------------|---|
| A First conductivity sensor | I Flow meter |
| B Flow cell block | J Sample collector |
| C Flow regulating valve | K Deaeration tube of cation exchanger bottle |
| D Pre-rinse inlet | L Deaeration tube of pre-rinse bottle |
| E Pre-rinse outlet | M Active cation exchanger bottle |
| F Pre-rinse inlet | N Sample outlet |
| G Sample inlet | |
| H Second conductivity sensor | |

Correction or calibration Not necessary, auto zero is performed automatically and continuously with each measurement.

Measuring principle When a voltage U is applied between two electrodes in an electrolyte solution, an electric field is generated. This field moves the ions in the solution: Cations move to the cathode; Anions move to the anode. At the electrodes, the ions gain or lose electrons which generates an electric current I . Using Ohm's law the resistance R of the solution in the measuring cell can be calculated from the applied voltage and the measured current: $R = U/I$.

The resistance obtained in this way depends on the specific conductivity κ of the solution and the geometry of the measuring cell. The influence of the measuring cell's geometry is taken into account by the cell constant ZK , which is used to calculate the specific conductivity from the resistance: $\kappa = ZK \cdot 1/R$. The unit of specific conductivity is $\mu S/cm$ or $\mu S/m$.

The cell constant ZK of a Swan conductivity sensor is determined during factory calibration and printed on the sensor label and certificate. Swan's UP-CON1000 sensors are designed so that the cell constant depends only on the sensor's geometry and not on that of the measuring cell. Hence, no additional calibration is required.

Calculation of pH and concentration The instrument supports the calculation of sample pH in the range of 7.5 to 10.5 according to VGBE-010-00-2023-08 and the calculation of the concentration of the alkalizing agent. The calculation of pH and concentration is based on the sample's specific conductivity and the conductivity after cation exchange. The following table provides the calculated values of the alkalizing agent concentrations required to achieve a pH of 10.2 at 25 °C.

Substance	c / ppm	pKa
Ammonia	30	9.25
Ethanolamine (ETA)	60	9.5
Morpholine	750	8.5
Cyclohexylamine (CHA)	25	10.63
2-Diethylaminoethanol (DEAE)	75	9.75
2-Amino-2-methylpropanol (AMP)	60	9.7
Strong bases (NaOH)	6.4	-

Concentrations of alkalizing agents for a pH of 10.2 at 25 °C.

Specific conductivity Specific conductivity represents the sum of the conductivity of all ions in the sample. In water-steam cycles that contain an alkalizing agent, conductivity is primarily determined by the alkalizing agent. The contribution of impurities is largely masked by the alkalizing agent.

**Cation (acid)
conductivity**

The alkalizing agent is completely removed by the cation exchanger, and all cations (positively charged ions) are exchanged for H^+ ions. Anions (negatively charged ions) pass through the column unchanged. Together with the H^+ ions and the ions resulting from the autoprotolysis of water, they determine the conductivity after cation exchange.

**Temperature
compensation**

The mobility of ions increases with temperature. As a result, the conductivity of the sample also increases. To ensure accurate measurement, the temperature of the sample is measured simultaneously using an integrated Pt1000 sensor. The conductivity is automatically compensated to a reference temperature of 25 °C. Different temperature compensation models are available for various water compositions.

The appropriate model according to the application must be selected. For cation conductivity, select the temperature compensation model for strong acids.

For more information see **Influence of Temperature on Electrical Conductivity, PPChem (2012)**.

**Standard
temperature**


The displayed conductivity value is compensated to 25 °C standard temperature.




2.2. Instrument Specification

Power supply	AC variant:	100–240 VAC (±10%) 50/60 Hz (±5%)
	DC variant:	10–36 VDC
	Power consumption	max. 35 VA
Sample requirements	Flow rate:	3–20 l/h
	Temperature:	up to 50 °C
	Inlet pressure:	up to 2 bar
	Outlet pressure:	pressure free
On-site requirements	The analyzer site must permit connections to:	
	Sample inlet:	Swagelok fitting with R 1/8" (ISO 7-1) thread for 1/4" tube OD
	Sample outlet:	for flexible tube, 15 mm inner Ø
Measuring range	Range	Resolution
	0.055 to 0.999 µS/cm	0.001 µS/cm
	1.00 to 9.99 µS/cm	0.01 µS/cm
	10.0 to 99.9 µS/cm	0.1 µS/cm
	100 to 999 µS/cm	1 µS/cm
	Accuracy: ±1 % of measured value or ±1 digit (whichever is greater) Ranges and accuracy valid for a cell constant of 0.0415 cm ⁻¹ (Swansensor UP-CON1000).	
Transmitter specifications	Housing:	aluminum, with a protection degree of IP 66 / NEMA 4X
	Ambient temperature:	-10 to +50 °C
	Humidity:	10–90% rel., non condensing
	Display:	backlit LCD, 74 × 53 mm

Dimensions	Panel:	stainless steel
	Dimensions:	280 × 850 × 200 mm
	Screws:	8 mm
	Weight:	10 kg




2.3. Instrument Overview



- | | |
|---------------------------------------|--------------------------------------|
| A Panel | G Flow regulating valve |
| B Transmitter | H Sample collector |
| C Specific conductivity sensor | I Active cation exchanger |
| D Cation conductivity sensor | J Pre-rinsed cation exchanger |
| E Flow cell | K Sample inlet |
| F Flow meter | L Sample outlet |

2.4. Single Components


2.4.1 AMI-II Transmitter



Specifications	Electronics case:	Cast aluminum
	Protection degree:	IP 66 / NEMA 4X
	Display:	backlit LCD, 74 x 53 mm
	Electrical connectors:	screw clamps

2.4.2 Swansensor UP-CON1000 SL

Two-electrode conductivity sensor for online measurement of ultra-pure water.




Measurement	Measuring range:	0.055µS/cm to 30 mS/cm
	Accuracy at 25 °C:	±1% of measured value
Operation and installation	Cell constant:	0.04 cm ⁻¹
	Temperature sensor:	Pt1000 (Class A, DIN EN 60751)
Measuring range and accuracy apply to the combination of Swansensor UP-CON1000 SL and AMI-II Deltacon Power.		
Operation and installation	Operating temperature:	-10 to 100 °C
	Operating pressure:	10 bar
	Process connection:	Slot-Lock for quick release of sensor
	Electrical connection:	fixed cable with end sleeves or M16 male plug (IP67)

2.4.3 Flow Cell CATCON+ SL

Flow cell for continuous measurement of conductivity before and after cation exchange in ultrapure water.

Dimensions



Sample conditions	Sample temperature:	max. 50°C
	Inlet pressure:	max. 2 bar
	Outlet pressure:	pressure free
	Sample flow	3 to 20 l/h
Process connections	Inlet:	Swagelok fitting with R $\frac{1}{8}''$ (ISO 7-1) thread for $\frac{1}{4}''$ tube OD
	Outlet:	8 mm Serto tube adapter (PA)
Material	Stainless steel 1.4404 (SS316L)	

3. Installation

3.1. Installation Checklist

On site requirements	AC variant: 100 – 240 VAC ($\pm 10\%$), 50/60 Hz ($\pm 5\%$). DC variant: 10 – 36 VDC. Power consumption: 35 VA maximum. Protective earth connection required. Sample line with sufficient sample flow and pressure (see p. 14).
Installation	Mount the instrument in vertical position. Display should be at eye level. Connect sample inlet and outlet. Single components: Mount the sensors and connect the cables.
Electrical wiring	Connect all external devices like limit switches and current loops according to the connection diagram (see p. 26). Connect power cord.
Cation exchanger	Fill up cation exchanger bottle with high purity water. Remove the empty bottle and install the cation exchanger bottle. With pre-rinse set-up, install a cation exchanger bottle to the second flange.
Power-up	Start sample flow and wait until flow cell is completely filled. Switch on power. Adjust sample flow.
Instrument setup	Program all sensor parameters, the required temperature compensation, all parameters for external devices (interface, recorders, etc.) and all parameters for instrument operation (limits, alarms).
Run-in period	If the conductivity value of the sample is very low, the sensor might need some time until the correct reading is displayed.

3.2. Mounting the Instrument

Mounting requirements

Mount the instrument in vertical position. The display should be at eye level to simplify operation and maintenance. The instrument is intended for indoor installation.

Dimensions

For panel dimensions, see [p. 15](#).
For dimensions of single components, see [p. 17](#).



3.3. Connecting Sample Inlet and Outlet

3.3.1 Stainless Steel Swagelok Fitting at Sample Inlet


Preparation

Cut the tube to length and deburr it. The tube must be straight and free from blemishes for approximately 1,5 x tube diameter from the end.

Lubrication with lubricating oil, MoS₂, Teflon etc. is recommended for the assembly and reassembly of bigger sized unions (thread, compression cone).

Installation

- 1 Insert the compression ferrule [C] and the compression cone [D] into the union nut [B].
- 2 Screw on the union nut onto the body, do not tighten it.
- 3 Push the stainless steel pipe through the union nut as far as it reaches the stop of the body.
- 4 Mark the union nut at 6 o'clock position.
- 5 While holding the fitting body steady, tighten the nut union 1¼ rotation using an open ended spanner.



A Stainless steel tube

B Union nut


C Compression ferrule

D Compression cone

E Body

F Tightened connection


3.3.2 FEP Tube at Sample Outlet



Connect the 15 mm tube [C] to the hose nozzle [B] and place it into the atmospheric drain.

3.4. Installation of Cation Exchanger

Install cation
exchanger
bottle



Install the resin bottle as follows:

- 1 Unscrew and remove the empty bottle [E] from the bottle holder [B].
- 2 Fill high purity water into the cation exchanger bottle [C], until the water level in the bottle reaches the beginning of the thread.
- 3 Carefully, without spilling water, push the cation exchanger bottle over the inlet filter holder [D] into the bottle holder [B].
- 4 Screw the cation exchanger bottle into the bottle holder.
- ⚠ *Do not tighten the bottle too firmly, this could damage the gasket.*
- 5 If you have a pre-rinse setup, proceed in the same way with the second cation exchanger bottle.

3.5. Electrical Connections



WARNING


Risk of electrical shock

Failure to follow safety instructions can result in serious injury or death.

- Before working on electrical components, turn off power to the instrument. External power sources connected to relay 1 or 2 or to the alarm relay must also be turned off.
- Do not connect the instrument to power unless the ground wire (PE) is connected.
- Make sure the power specification of the instrument corresponds to the power on site.

Cable thicknesses

In order to comply with IP66, use the following cable thicknesses. Protect unused cable glands.



A M16 cable glands (3x): cable $\varnothing_{outer}$ 5–10 mm


B M12 cable glands (11x): cable $\varnothing_{outer}$ 3–6 mm

Wires

For power and relays: Use max. 1.5 mm² / AWG 14 stranded wire with end sleeves.

For signal outputs and input: Use 0.25 mm² / AWG 23 stranded wire with end sleeves.

3.5.1 Connection Diagram




CAUTION



Use only the terminals shown in this diagram, and only for the mentioned purpose. Use of any other terminals will cause short circuits with possible corresponding consequences to material and personnel.

3.5.2 Power Supply



- A** Neutral conductor, terminal 2
- B** Phase conductor, terminal 1
- C** Power supply connector
- D** Protective earth PE

Installation requirements

The installation must meet the following requirements.

- ♦ Mains cable according to standards IEC 60227 or IEC 60245; flammability rating FV1.
- ♦ Mains equipped with an external switch or circuit-breaker
 - near the instrument
 - easily accessible to the operator
 - marked as interrupter for AMI-II Deltacon Power

3.6. Relay Contacts

3.6.1 Input

Use only potential-free (dry) contacts.

Terminals: 39/40

3.6.2 Alarm Relay

One alarm output for system errors.

- ♦ Normally open contact (terminals: 21/22):
Active (closed) when no error is present. Inactive (opened) on error and loss of power.
- ♦ Normally closed contact (terminals: 22/23):
Active (opened) when no error is present. Inactive (closed) on error and loss of power.

Max. load: 1 A/250 VAC.

For switching inductive loads, please observe the information in section [Types of Loads](#), p. 29.

3.6.3 Relay 1 and 2


- ♦ Relay 1:
 - terminals 35/36 (normally open) or
 - terminals 35/20 (normally closed).
- ♦ Relay 2: terminals 37/38 (normally open).

Max. load 1 A/250 VAC.

For switching inductive loads, please observe the information in section [Types of Loads](#), p. 29.

3.6.4 Types of Loads


Inductive loads Small inductive loads (max 0.1 A) as for example the coil of a power relay can be switched directly. To avoid noise voltage in the AMI-II transmitter it is mandatory to connect a snubber circuit in parallel to the load.



- A** AC or DC power supply
- B** AMI-II transmitter
- C** External power relay
- D** Snubber
- E** Power relay coil

To switch inductive loads higher than 0.1 A, use suitable power relays.

Resistive loads Resistive loads (max. 1 A) and control signals for PLC, impulse pumps and so on can be connected without further measures.



- A** AMI-II transmitter
- B** PLC or controlled pulse pump
- C** Logic

3.7. Signal Outputs

3.7.1 Signal Output 1 and 2 (Current Outputs)


Max. burden 510 Ω .

If signals are sent to two different receivers, use signal isolator (loop isolator).

Signal output 1: Terminals 17 (+) and 16 (-)

Signal output 2: Terminals 18 (+) and 16 (-)

3.8. Interface Options



- A** AMI-II transmitter
- B** SD card slot
- C** Cable grommet
- D** Screw terminals
- E** Frontend
- F** Communication option

The slot for interfaces can be used to expand the functionality of the AMI-II transmitter with either:

- ♦ Two additional signal outputs
- ♦ Profibus or Modbus
- ♦ HART


3.8.1 Signal Outputs 3 and 4

Max. burden 510 Ω .

If signals are sent to two different receivers, use signal isolator (loop isolator).

Signal output 3: terminals 71 (+) and 70 (-).


Signal output 4: terminals 73 (+) and 72 (-).



3.8.2 RS485 (Profibus or Modbus Protocol)

Terminal 74/75 PB, terminal 70/71 PA, terminal 72/73 shield


The switch [A] must be set to "ON" if only one instrument is installed or on the last instrument in the bus.



A On/off switch

3.8.3 HART

Terminals 71 (+) and 70 (-).



4. Instrument Setup

4.1. Establish Sample Flow

- 1** Open flow regulating valve.
- 2** Wait until the flow cell has been completely filled.
- 3** Switch on power.
- 4** Adjust the sample flow to 3–20 l/h (5–10 l/h recommended).
- 5** Let the instrument run in for 1 h.
⇒ *This recommendation is valid for high purity, strong acid cation exchange resin delivered by Swan. Lower quality resin from other suppliers may require a longer run-in period of up to several days.*




4.2. Programming

Sensor parameters	Menu 5.1.2.1, sensor 1		
	Menu 5.1.2.2, sensor 2		
	The sensor characteristics are printed on the label of each sensor.		
	87-344.203	UP-CON1000SL	Sensor type
	SW-xx-xx-xx	ZK = 0.0417	Cell constant
	SWAN AG	DT = 0.06 °C	Temperature correction
	Enter for each sensor separately the:		
	♦ Cell constant [cm ⁻¹]		
	♦ Temperature correction [°C]		
	♦ Cable length: If the transmitter and the flow cell are mounted together on one panel, set the cable length to 0.0 m.		
	♦ Temperature compensation: The default setting for sensor 1 (specific conductivity) is ammonia. For sensor 2 (cation conductivity), the default setting is strong acids.		
Calculations	Menu 5.1.1.1		
	Set Calculations to “Yes” if you want to have pH and concentration of alkalization agent calculated and displayed.		
Measuring unit	Menu 5.1.1.2		
	Set the measuring unit:		
	♦ µS/cm		
	♦ µS/m		
Display	Menu 4.4.1, Screen 1		
	Menu 4.4.2, Screen 2		
	Select the values to be displayed on screens 1 and 2.		
External devices	Menu 5.2 Signal Outputs		
	Menu 5.4 Interface		
Limits and alarms	Menu 5.3 Relay Contacts		
	Program all parameters for instrument operation (limits, alarms).		


5. Operation

5.1. Keys




- A** to exit a menu or command (rejecting any changes)
to move back to the previous menu level
- B** to move down in a menu list and to decrease digits
- C** to move up in a menu list and to increase digits
to switch between display 1 and 2
- D** to open a selected menu item
to accept an entry

Program access, exit



5.2. Display



- A** RUN Normal operation
- HOLD Input active or cal delay: Instrument on hold (shows status of signal outputs)
- OFF Input active: Signal outputs go to 0/4 mA.
- B** Error  Non-fatal error  Fatal error
- C** Keys locked, transmitter control via Profibus
- D** Time
- E** Process values (SC: Specific conductivity, CC: Cation conductivity)
- F** Sample temperature 2
- G** Sample temperature 1
- H** Sample flow
- I** Relay status


Symbols used for relay status:

-   Upper/lower limit not yet reached
-   Upper/lower limit reached
-  Control upw./downw. no action
-  Control upw./downw. active, dark bar indicates control intensity
-  Timer
-  Timer: timing active (hand rotating)
-  Relay inactive (controlled via fieldbus)
-  Relay active (controlled via fieldbus)


**Switching
between
screens**

Toggle between screens 1 and 2 using the  key.

Example of screen 1:



Example of screen 2:



5.3. Software Structure

Main Menu	1
Messages	▶
Diagnostics	▶
Maintenance	▶
Operation	▶
Installation	▶

Messages	1.1
Pending Errors	▶
Maintenance List	▶
Message List	▶

Menu 1 Messages

Shows pending errors as well as the event history (time and state of events that have occurred at an earlier point of time).
Contains user-relevant data.

Diagnostics	2.1
Identification	▶
Sensors	▶
Sample	▶
I/O State	▶
SD Card	▶

Menu 2 Diagnostics

Provides user-relevant instrument and sample data.

Maintenance	3.1
Simulation	▶
Change of Resin	No
Set Time	23.09.06 16:30:00

Menu 3 Maintenance

For instrument calibration, relay and signal output simulation, and to set the instrument time.
Used by service personnel.

Operation	4.1
Sensors	▶
Relay Contacts	▶
Logger	▶
Display	▶

Menu 4 Operation

User-relevant parameters that might need to be modified during daily routine. Normally password protected and used by the process operator.
Subset of menu 5 - Installation, but process related.

Installation	5.1
Sensors	▶
Signal Outputs	▶
Relay Contacts	▶
Miscellaneous	▶
Interface	▶

Menu 5 Installation

For initial instrument set up by Swan authorized person.
Password protection strongly recommended.

5.4. Changing Parameters and Values

Changing parameters

The following example shows how to change the logger interval:

Logger 4.4.1
Log interval 30 min
Clear logger no
Eject SD Card <Enter>

1 Select the parameter you want to change.

2 Press [Enter].

Logger 4.1.3
Log interval Interval. ↓
Clear log 5 min
Eject SD 10 min
30 min
1 Hour

3 Press ▲ or ▼ to highlight the required parameter.

4 Press [Enter] to confirm the selection or [Exit] to keep the previous parameter).

⇒ The selected parameter is highlighted (but not saved yet).

Logger 4.1.3
Log interval 10 min
Clear logger no
Eject SD Card <Enter>

5 Press [Exit].

⇒ Yes is highlighted.

Logger 4.1.3
Log interval Save ? driven
Clear log no
Eject SD Yes
No

6 Press [Enter] to save the new parameter.

Changing values

Conductivity 5.3.1.1.1
Alarm High 3000 µS
Alarm Low 0.000 µS
Hysteresis 10.0 µS
Delay 5 Sec

1 Select the value you want to change.

2 Press [Enter].

3 Set required value with ▲ or ▼.

Conductivity 5.3.1.1.1
Alarm High 2500 µS
Alarm Low 0.000 µS
Hysteresis 10.0 µS
Delay 5 Sec

4 Press [Enter] to confirm the new value.

5 Press [Exit].

⇒ Yes is highlighted.

6 Press [Enter] to save the new value.

6. Maintenance

6.1. Maintenance Schedule

Monthly	♦ Check sample flow. ♦ Check cation exchange resin. The color changes to brown when it is depleted.
As needed	♦ Clean conductivity sensors. ♦ Replace filter. ♦ Replace deaeration tubes. ♦ Perform a verification measurement.

Reagent consumption At 1 ppm of alkalizing agent (pH 9.4 with ammonia), a one-liter bottle of cation exchange resin (exchange capacity 1.8 eq/l) lasts for:


- ♦ 3.5 months at a sample flow of 10 l/h,
- ♦ 7 months at a sample flow of 5 l/h.

These calculations include a safety margin of 15%.

6.2. Stop of Operation for Maintenance

- 1 Stop sample flow.
- 2 Shut off power of the instrument.

6.3. Maintenance of the Sensor



6.3.1 Remove the Sensor from the Flow Cell

To remove the sensor from the flow cell proceed as follows:

- 1 Press the security pin [B] down.
- 2 Turn the locking screw [C] 180° counterclockwise with a 5 mm allen key.
⇒ *The security pin remains down.*
- 3 Remove the sensor.

Cleaning If the sensor is slightly contaminated, clean it with soapy water and a pipe cleaner. If the sensor is strongly contaminated, dip the tip of the sensor into 5% hydrochloric acid for a short time.


6.3.2 Install the Sensor into the Flow Cell

- 1 Make sure that the locking mechanism is in unlocked position (locking screw in position [C] and security pin in position [B]).
- 2 Put the sensor into the flow cell with the alignment marks [E] in line.
- 3 Turn the locking screw with a 5 mm Allen key clockwise 180°.
⇒ *The security pin moves up in lock position.*

6.4. Changing the Cation Exchanger

The resin of the ion exchanger changes its color from dark violet to brown if the capacity is exhausted. The resin should be changed before no violet resin is left or the cation conductivity rises above the normal value.

Without pre-rinse option




- 1 Stop sample flow.
- 2 Slightly squeeze the exhausted cation exchanger bottle [E] before removing.
⇒ *Thus no water will spill out of the flow cell when loosening the bottle.*
- 3 Unscrew and carefully remove the exhausted cation exchanger bottle [E].
- 4 Fill high purity water into the new cation exchanger bottle [C], until the water level in the bottle reaches the beginning of the thread.
- 5 Carefully, without spilling water, push the cation exchanger bottle over the inlet filter holder [D] into the bottle holder [B].

- 6 Screw the cation exchanger bottle into the bottle holder.
- ① *Do not tighten the bottle too firmly, this could damage the gasket.*
- 7 Navigate to menu **Maintenance > Change of Resin** and select “Yes”.
- 8 Open and adjust the sample flow.
- 9 Rinse the new cation exchanger resin until the display shows stable measured values.




With pre-rinse option



- 1 Stop sample flow.
- 2 Slightly squeeze the exhausted cation exchanger bottle [F] before removing.
 ⇒ *Thus no water will spill out of the flow cell when loosening the bottle.*
- 3 Unscrew and carefully remove the exhausted cation exchanger bottle [F].
- 4 Unscrew and carefully remove the pre-rinsed cation exchanger bottle [D] from the pre-rinse holder [C].
- 5 Carefully, without spilling water, push the cation exchanger bottle [D] over the inlet filter holder [E] into the bottle holder [B].
- 6 Screw the cation exchanger bottle into the bottle holder.
- ❗ *Do not tighten the bottle too firmly, this could damage the gasket.*
- 7 Navigate to menu **Maintenance > Change of Resin** and select "Yes".
- 8 Install a new bottle with fresh, unused resin into the pre-rinse bottle holder [C].
 ⇒ *The new cation exchanger resin will be pre-rinsed and ready for use when the next exchange is necessary.*

Operation time 1 liter Swan resin

This graphic shows the average depletion time (flow 6 l/h) and must be verified by the user.




Cation Conductivity.

Operational days for 1 l of cation exchange resin with an exchange capacity of 1.8 eq/l.

Flow rate 6 l/h alkalization with ammonia (safety margin of 15% subtracted).


6.5. Changing the Inlet Filter

The inlet filter of the cation exchanger prevents the resin from entering the flow cell. It is located in the inlet filter holder [B].



- 1 Stop sample flow.
 - 2 Slightly squeeze the cation exchanger bottle [E] before removing.
⇒ *Thus no water will spill out of the flow cell when loosening the bottle.*
 - 3 Unscrew and carefully remove the cation exchanger bottle.
 - 4 For better access to the allen screws [C] unscrew and remove the filter holder [B] from the bottle holder [A].
 - 5 Loosen the 4 allen screws with a 1.5 mm allen key.
 - 6 Carefully remove the inlet filter [D] with a screw driver no.0 from the inlet filter holder.
 - 7 Insert a new inlet filter.
 - 8 Tighten the 4 allen screws slightly.
 - 9 Mount the filter holder back onto the bottle holder.
 - 10 Screw the cation exchanger bottle into the bottle holder.
- ❗ *Do not tighten the bottle too firmly, this could damage the gasket.*

6.6. Tube Connections




6.7. Replace the Deaeration Tubes

Depending on your application, it might be necessary to change the deaeration tube, e.g. when contaminated with iron.

Note: *There are two different tubes:*

- ♦ The deaeration tube [F] of the cation exchanger bottle has an inner diameter of 1 mm.
- ♦ The deaeration tube [E] of the pre-rinse bottle, has an inner diameter of 2 mm.

- Preparation**
- 1 Close the main tap to stop the sample flow.
 - 2 Remove cation exchanger bottle from the bottle holder [H].



- | | |
|---|---|
| A Flow cell | G Tube fitting |
| B Flow meter | H Bottle holder of cation exchanger bottle |
| C Pre-rinse inlet | I Panel |
| D Sample collector | J Bottle holder of pre-rinse bottle |
| E Deaeration tube of pre-rinse bottle | K Flow regulating valve |
| F Deaeration tube of cation exchanger bottle | |

6.7.1 Exchange Deaeration Tube of Cation Exchanger Bottle

- 1 Remove the inlet tube [C] to the pre-rinsed cation exchanger bottle from the flowmeter [B].
- 2 Remove the flowmeter [B] from the flow cell [A].
- 3 Remove the sample collector [D] from the panel [I].
- 4 Unscrew and remove the tube fittings of the deaeration tubes [E] and [F] from the sample collector.
- 5 Unscrew and remove the bottle holder [H] from the flow cell [A].
- 6 Unscrew and remove the tube fitting [G] from the bottle holder [H].
- 7 Replace the 1 mm deaeration tube [F].
- 8 Screw the tube fitting into the bottle holder and tighten it.
- 9 Screw the bottle holder to the flow cell.
- 10 Screw the cation exchanger bottle into the bottle holder.
- ❗ *Do not tighten the bottle too firmly, this could damage the gasket.*
- 11 Before installing the sample collector [D] and the flowmeter [B] replace the deaeration tube [E], see following chapter.

6.7.2 Exchange Deaeration Tube of Pre-Rinse Bottle

- 1 Unscrew and remove the flow regulating valve [K], with a 14 mm open-end wrench from the flow cell.
- 2 Unscrew and remove the tube Fitting from the bottle holder [J].
- 3 Replace the 2 mm deaeration tube [E].
- 4 Screw the flow regulating valve into the flow cell and tighten it well.

Assemble


- 1 Screw the sample collector onto the panel.
- 2 Screw the flow meter [B] onto the flow cell [A].
- 3 Connect the inlet tube [C] to the pre-rinsed cation exchanger bottle with the elbow union of the flowmeter [B].

6.8. Quality Assurance of the Instrument

To perform a comparative measurement with the AMI INSPECTOR Conductivity, proceed as follows.

Specific conductivity


- 1 Stop sample flow to the AMI-II Deltacon Power by closing the corresponding valve (e.g. on the Back Pressure Regulator).
- 2 Connect the AMI INSPECTOR as shown below.
- 3 Switch on the AMI INSPECTOR.
- 4 Start the sample flow and regulate it to approximately 10 l/h using the flow regulating valve [C].
- 5 On the AMI INSPECTOR, navigate to **Installation > Sensors > Temp. compensation** and program the same temperature compensation as for sensor 1 of the AMI-II Deltacon Power.
- 6 Wait until the value has stabilized.



- | | |
|---|---------------------------------------|
| A Flow cell of AMI-II Deltacon Power | C Flow regulating valve |
| B Flow cell of AMI INSPECTOR | D Sample inlets with T-fitting |
| | E Sample outlets |

Acid conductivity

- 1 Stop sample flow to the AMI-II Deltacon Power by closing the corresponding valve (e.g. on the Back Pressure Regulator).
- 2 Connect the AMI INSPECTOR as shown below.
- 3 Switch on the AMI INSPECTOR.
- 4 Fully open the flow regulating valve [D] of the AMI INSPECTOR.
- 5 Start the sample flow and regulate it to approximately 10 l/h using the flow regulating valve [B] of the AMI-II Deltacon Power.
- 6 On the AMI INSPECTOR, navigate to **Installation > Sensors > Temp. compensation** and program "Strong acids".
- 7 Wait until the value has stabilized.



- | | |
|---|--------------------------------|
| A Flow cell of AMI-II Deltacon Power | D Flow regulating valve |
| B Flow regulating valve | E Supplied FEP tube |
| C Flow cell of AMI INSPECTOR | F Sample outlet |
| | G Sample inlet |

**Completion of
the measure-
ment**

- 1 Stop the sample flow to the AMI-II Deltacon Power by closing the appropriate valve, e.g. on the Back Pressure Regulator.
- 2 Disconnect the AMI INSPECTOR from the sample line.
- 3 Start and regulate sample flow to the AMI-II Deltacon Power.
- 4 Shut off the AMI INSPECTOR .

6.9. Longer Stop of Operation

- 1** Stop sample flow.
- 2** Shut off power of the instrument.
- 3** Slightly squeeze the cation exchanger bottle.
⇒ *Thus no water will spill out of the flow cell when loosening the bottle.*
- 4** Unscrew and carefully remove the cation exchanger bottle with the exhausted resin.
- 5** Close the cation exchanger bottle with the screw cover and store it in a frost-protected room.
- 6** Screw on an empty bottle.



7. Troubleshooting

This chapter provides some hints to make troubleshooting easier. For information on how to handle/clean parts refer to [Maintenance, p. 40](#).

For information on how to program the instrument refer to [Program List and Explanations, p. 66](#).

If you need help please contact your local distributor. Note serial number of instrument and all diagnostic values before.

**Conditions for
pH calculation**

- ♦ Only 1 alkalization agent (acid-base pair) in the sample. No mixture.
- ♦ The contamination is mostly NaCl.
- ♦ Phosphate concentration is <0.5 ppm.
- ♦ If pH value is <8, the concentration of contaminant must be small compared to the concentration of the alkalization agent.
- ♦ pH value is >7.5, and <10.5.

What to do if...

Problem	Possible reason / solution
Conductivity value <0.055 µS/cm	♦ Air bubble at sensor tip or sensor in air.
High cation conductivity after resin change	♦ Cation exchange resin not rinsed. Wait until the cation conductivity has returned to a normal level. ♦ Use Swan cation exchange resin. Lower quality resin from other suppliers may require a long run-in period of up to several days.
No pH/alkalization agent value available on the display and in the menus for the relays and signal outputs	♦ Switch on calculations in menu Installation > Sensors > Miscellaneous > Calculations. ♦ Afterwards program screen 1 and 2 in menus Operation > Display > Screen 1 and Operation > Display > Screen 2.

7.1. Error List

Two categories of messages are distinguished:

Non-fatal error ◀

Non-fatal instrument error or exceeding of a programmed limit value. Such errors are marked **E0xx** (bold and black) in the following list.

Fatal error -⚡- (flashing symbol)

Fatal instrument error. Control is interrupted and the displayed measured values may not be correct.

Fatal errors are divided into the following two subcategories:

- ♦ Errors which disappear when correct measuring conditions are recovered (i.e. sample flow low).
Such errors are marked **E0xx** (bold and orange) in the following list.
- ♦ Errors which indicate a hardware failure of the instrument.
Such errors are marked **E0xx** (bold and red) in the following list.

Error	Description	Corrective action
E001	Cond. 1 Alarm high	– Check process. – Check programmed value.
E002	Cond. 1 Alarm low	– Check process. – Check programmed value.
E003	Cond. 2 Alarm high	– Check process. – Check programmed value.
E004	Cond. 2 Alarm low	– Check process. – Check programmed value.
E007	Temp. 1 high	– Check process. – Check programmed value.
E008	Temp. 1 low	– Check process. – Check programmed value.
E009	Sample Flow high	– Check sample inlet pressure.
E010	Sample Flow low	– Check sample inlet pressure. – Check flow regulating valve. – Check programmed value.
E011	Temp. 1 shorted	– Check wiring of temperature sensor. – Check temperature sensor.
E012	Temp. 1 disconnected	– Check wiring of temperature sensor. – Check temperature sensor.
E013	Case Temp. high	– Check case/environment temperature. – Check programmed value.
E014	Case Temp. low	– Check case/environment temperature. – Check programmed value.
E015	pH Calculation undef.	– Check process. – Check if conditions for pH calculation are met.
E017	Control timeout	– Check control device or programming in menus Installation > Relay contacts > Relay 1 and Installation > Relay contacts > Relay 2.
E019	Temp. 2 shorted	– Check wiring of temperature sensor. – Check temperature sensor.


Error	Description	Corrective action
E020	Temp. 2 disconnected	– Check wiring of temperature sensor. – Check temperature sensor.
E024	Input active	– Message informing that the relay input has been actuated. – Can be deactivated in menu Installation > Relay contacts > Input > Fault.
E026	IC LM75	– Call support.
E030	I2C Frontend	– Call support.
E031	Calibration Recout	– Call support.
E032	Wrong Frontend	– Call support.
E033	pH Alarm high	– Check process. – Check programmed value.
E034	pH Alarm low	– Check process. – Check programmed value.
E035	Alk. Alarm high	– Check process. – Check programmed value.
E036	Alk. Alarm low	– Check process. – Check programmed value.
E037	Temp. 2 high	– Check process. – Check programmed value.
E038	Temp. 2 low	– Check process. – Check programmed value.
E049	Power-on	– None, normal status.
E050	Power-down	– None, normal status.
E067	Resin depleted	– Exchange the cation exchanger bottle.



7.2. Replacing Fuses

When a fuse has blown, find out the cause and fix it before replacement. Use tweezers or needle-nosed pliers to remove the defective fuse.

Use original fuses provided by Swan only.



A 0.8 AT/250V Instrument power supply

8. Program Overview

Explanations for each parameter of the menus can be found in [Program List and Explanations, p. 66](#).

- ♦ Menu 1 **Messages** informs about pending errors and maintenance tasks and shows the error history. Password protection possible. No settings can be modified.
- ♦ Menu 2 **Diagnostics** is accessible to anyone at any time. No password protection. No settings can be modified.
- ♦ Menu 3 **Maintenance** is intended for service technicians: Calibration, simulation of outputs and set time/date. Please protect with password.
- ♦ Menu 4 **Operation** is intended for the user and enables setting of limit values, alarm values, etc. The presetting is made in the Installation menu (for the system engineer only). Please protect with password.
- ♦ Menu 5 **Installation**: Defining assignment of all inputs and outputs, measuring parameters, interface, passwords, etc. Menu for the system engineer. Password strongly recommended.

8.1. Messages (Main Menu 1)

Pending Errors	Pending Errors	1.1.5*	* Menu numbers
1.1*			
Maintenance List	Maintenance List	1.2.5*	
1.2*			
Message List	Number	1.3.1*	
1.3*	Date, Time		



8.2. Diagnostics (Main Menu 2)

Identification	Designation	* Menu numbers		
2.1*	Version			
	Bootloader			
	Factory Test	Motherboard	2.1.4.1*	
	2.1.4*	Front End		
	Operating Time	Years, days, hours, minutes, seconds	2.1.5.1*	
2.2*	Conductivity	Sensor 1	Current value	2.2.1.1.1*
			Raw value	
			Cell constant	
	Sensor 2	2.2.1.2*	Current value	2.2.1.2.1*
			Raw value	
			Cell constant	
	Miscellaneous	Case Temp.	2.2.2.1*	
	Sample ID	2.3.1*		
2.3*	Sample Temp.	Temp.1	2.3.2.1*	
		(Pt1000)		
		Temp.2		
	Sample Flow	Sample Flow	2.3.3.1*	
		Raw value		
2.4*	Relays	Alarm Relay	2.4.1.1*	
		Relay 1/2		
		Input		
	Signal Outputs	Signal Output 1/2/3/4	2.4.2.1*	
2.5*	SD Card	State	2.5.1*	
2.6*	Interface	Protocol	2.6.1*	(only with RS485 interface)
		Baud rate		

8.3. Maintenance (Main Menu 3)

Simulation	Relays	Alarm Relay	3.1.1.1*	* Menu numbers
3.1*	3.1.1*	Relay 1	3.1.1.2*	
		Relay 2	3.1.1.3*	
	Signal Outputs	Signal Output 1	3.1.2.1*	
	3.1.2*	Signal Output 2	3.1.2.2*	
Change of Resin				
3.2*				
Set Time	(Date), (Time)			
3.3*				

8.4. Operation (Main Menu 4)

Sensors	Filter Time Const.	4.1.1*		* Menu numbers
4.1*	Hold after Cal	4.1.2*		
Relay Contacts	Alarm Relay	Cond. 1 (sc)	Alarm High	4.2.1.1.1*
4.2*	4.2.1*	4.2.1.1*	Alarm Low	4.2.1.1.25*
			Hysteresis	4.2.1.1.35*
			Delay	4.2.1.1.45*
		Cond. 2 (cc)	Alarm High	4.2.1.2.1*
		4.2.1.2*	Alarm Low	4.2.1.2.25*
			Hysteresis	4.2.1.2.35*
			Delay	4.2.1.2.45*
		pH	Alarm High	4.2.1.3.1*
		4.2.1.3*	Alarm Low	4.2.1.3.25*
			Hysteresis	4.2.1.3.35*
			Delay	4.2.1.3.45*
		Ammonia	Alarm High	4.2.1.4.1*
		4.2.1.4*	Alarm Low	4.2.1.4.25*
			Hysteresis	4.2.1.4.35*
			Delay	4.2.1.4.45*
	Relay 1/2	Parameter		
	4.2.2*/4.2.3*	Setpoint	4.2.x.200*	
		Hysteresis	4.2.x.300*	
		Delay	4.2.x.40*	
	Input	Active	4.2.4.1*	
	4.2.4*	Signal Outputs	4.2.4.2*	
		Output / Control	4.2.4.3*	
		Fault	4.2.4.4*	
		Delay	4.2.4.5*	
Logger	Log Interval	4.3.1*		
4.3*	Clear Logger	4.3.2*		
	Eject SD Card	4.3.3*		

Display 4.4*	Screen 1 4.4.1*	Row 1	4.4.1.1*	* Menu numbers
		Row 2	4.4.1.2*	
		Row 3	4.4.1.3*	
	Screen 2 4.4.2*	Row 1	4.4.2.1*	
		Row 2	4.4.2.2*	
		Row 3	4.4.2.3*	

8.5. Installation (Main Menu 5)

Sensors	Miscellaneous	<i>Calculations</i>	5.1.1.1*	* Menu numbers
5.1*	5.1.1*	<i>Maes. unit</i>	5.1.1.2*	
		<i>Monitoring of resin</i>	5.1.1.3*	
		<i>Resin Capacity</i>	5.1.1.4*	
		<i>Volume of resin</i>	5.1.1.5*	
	Sensor parameters	Sensor 1	<i>Cell Constant</i>	5.1.2.1.1*
	5.1.2*	5.1.2.1*	<i>Temp. Corr.</i>	5.1.2.1.2*
			<i>Cable length</i>	5.1.2.1.3*
			Temp. comp.	<i>Comp.</i>
			5.1.2.1.5*	5.1.2.1.5.1*
		Sensor 2	<i>Cell Constant</i>	5.1.2.2.1*
		5.1.2.2*	<i>Temp. Corr.</i>	5.1.2.2.2*
			<i>Cable length</i>	5.1.2.2.3*
			Temp. comp.	<i>Comp.</i>
			5.1.2.2.5*	5.1.2.2.5.1*
Signal Outputs	Signal Output 1/2	<i>Parameter</i>	5.2.1.1/5.2.2.1*	
5.2*	5.2.1/5.2.2*	<i>Current Loop</i>	5.2.1.2/5.2.2.2*	
		<i>Function</i>	5.2.1.3/5.2.2.3*	
		Scaling	<i>Range Low</i>	5.2.x.40.10/11*
		5.2.x.40	<i>Range High</i>	5.2.x.40.20/21*
Relay Contacts	Alarm Relay	Conductivity	Cond. 1 (sc)	<i>Alarm High</i>
5.3*	5.3.1*	5.3.1.1*	5.3.1.1.1*	<i>Alarm Low</i>
				<i>Hysteresis *</i>
				<i>Delay</i>
			Cond. 2 (cc)	<i>Alarm High</i>
			5.3.1.1.2*	<i>Alarm Low</i>
				<i>Hysteresis *</i>
				<i>Delay</i>
			pH	<i>Alarm High</i>
			5.3.1.1.3*	<i>Alarm Low</i>
				<i>Hysteresis</i>
				<i>Delay</i>

			Ammonia	<i>Alarm High</i>
			5.3.1.1.4*	<i>Alarm Low</i>
				<i>Hysteresis</i>
				<i>Delay</i>
		Sample Temp.	Temp. 1	<i>Alarm High</i>
		5.3.1.2*	5.3.1.2.1*	<i>Alarm Low</i>
			Temp. 2	<i>Alarm High</i>
			5.3.1.2.2*	<i>Alarm Low</i>
		Sample Flow	<i>Flow Alarm</i>	5.3.1.3.1*
		5.3.1.3*	<i>Alarm high</i>	5.3.1.3.2*
			<i>Alarm low</i>	5.3.1.3.3*
		Case Temp.	<i>Alarm High</i>	5.3.1.4.1*
		5.3.1.4*	<i>Alarm low</i>	5.3.1.4.2*
	Relay 1/2	<i>Function</i>	5.3.2.1 / 5.3.3.1*	* Menu numbers
	5.3.2/5.3.3*	<i>Parameter</i>	5.3.2.20 / 5.3.3.20*	
		<i>Setpoint</i>	5.3.2.300 / 5.3.3.301*	
		<i>Hysteresis</i>	5.3.2.400 / 5.3.3.401*	
		<i>Delay</i>	5.3.2.50 / 5.3.3.50*	
	Input	<i>Active</i>	5.3.4.1*	
	5.3.4*	<i>Signal Outputs</i>	5.3.4.2*	
		<i>Output/Control</i>	5.3.4.3*	
		<i>Fault</i>	5.3.4.4*	
		<i>Delay</i>	5.3.4.5*	
Miscellaneous	<i>Language</i>	5.4.1*		
5.4*	<i>Set defaults</i>	5.4.2*		
	<i>Load Firmware</i>	5.4.3*		
	Password	<i>Messages</i>	5.4.4.1*	
	5.4.4*	<i>Maintenance</i>	5.4.4.2*	
		<i>Operation</i>	5.4.4.3*	
		<i>Installation</i>	5.4.4.4*	
	<i>Sample ID</i>	5.4.5*		
Interface	<i>Protocol</i>	5.5.1*		(only with RS485
5.5*	<i>Device Address</i>	5.5.21*		interface)
	<i>Baud Rate</i>	5.5.31*		
	<i>Parity</i>	5.5.41*		

9. Program List and Explanations

1 Messages

1.1 Pending Errors

- 1.1.5 Provides the list of active errors with their status (active, acknowledged). When all active errors have been acknowledged, the alarm relay is active again. Cleared errors are moved to the message list.

1.2 Maintenance List

- 1.2.5 Provides the list of necessary maintenance. Cleared maintenance messages are moved to the message list.

1.3 Message List

- 1.3.1 Shows the error history: Error code, date and time of issue and status (active, acknowledged, cleared). 64 errors are memorized. Then the oldest error is cleared to save the newest one (circular buffer).

2 Diagnostics

2.1 Identification

Desig.: Designation of the instrument.
Version: Version of the instrument firmware.
Bootloader: Version of the bootloader.

- 2.1.4 **Factory Test:** Test date of the mainboard and frontend.

- 2.1.5 **Operating Time:** Years, days, hours, minutes, seconds.

2.2 Sensors

2.2.1 Conductivity

2.2.1.1 Sensor 1

Current value in μS
Raw value in μS
Cell Constant

- 2.2.1.1.4 **Factory Data:** Values of the factory calibration.

- 2.2.1.2 **Sensor 2:** See sensor 1.

2.2.2 Miscellaneous

- 2.2.2.1 *Case Temp:* Shows the current temperature in $^{\circ}\text{C}$ inside the transmitter.

2.3 Sample

2.3.1 *Sample ID*: Shows the ID used to identify the location of the sample.

2.3.2 *Sample Flow*: Shows the current sample flow in l/h and the raw value in Hz.

2.3.3 Sample Temp

2.3.3.1 *Temp 1*: Shows the current sample temperature at sensor 1 in °C.

(Pt 1000): Shows the current temperature at sensor 1 in Ohm.

Temp 2: Shows the current sample temperature at sensor 2 in °C.

(Pt 1000): Shows the current temperature at sensor 2 in Ohm.

2.3.4 *Resin Capacity*: Remaining capacity of the resin in percent.

2.3.5 *Change of Resin*: Date of the last resin change.

2.4 I/O State

2.4.1 Relays

2.4.1.1 *Alarm Relay*: Active or inactive

Relays 1 and 2: Active or inactive

Input: Open or closed

2.4.2 Signal Outputs

2.4.2.1 *Signal Outputs 1 and 2*: Current in mA

Signal Outputs 3 and 4: Current in mA (if option is installed)

2.5 SD Card

2.5.1 *Status*: Shows the status of the SD card.

2.6 Interface

Settings of the installed communication option (if any).

3 Maintenance

3.1 Simulation

To simulate a value or a relay state, select

- ◆ alarm relay
- ◆ relay 1 or 2
- ◆ signal outputs 1 or 2
- ◆ signal outputs 3 or 4 (if option is installed)

Change the value or state of the selected item with the arrow keys.
Press [Enter].

⇒ *The value is simulated by the relay/signal output.*

At the absence of any key activities, the instrument will switch back to normal mode after 20 min.

3.1.1 Relays

3.1.1.1	<i>Alarm relay:</i>	Active or inactive
3.1.1.2	<i>Relay 1:</i>	Active or inactive
3.1.1.3	<i>Relay 2:</i>	Active or inactive

3.1.2 Signal outputs

3.1.2.1	<i>Signal output 1:</i>	Current in mA
3.1.2.2	<i>Signal output 2:</i>	Current in mA
3.1.2.3	<i>Signal output 3:</i>	Current in mA
3.1.2.4	<i>Signal output 4:</i>	Current in mA

3.2 Change of Resin

Sets back the counter after changing the cation exchanger bottle.
Only visible if “Monitoring of Resin” has been set to “yes” in the Installation menu.

3.3 Set Time

Adjust date and time.

4 Operation

4.1 Sensors

- 4.1.1 *Filter Time Constant:* Used to damp noisy signals. The higher the filter time constant, the slower the system reacts to changes of the measured value.
Range: 5–300 s
- 4.1.2 *Hold after Cal.:* Delay permitting the instrument to stabilize again after calibration. During calibration plus hold time, the signal outputs are frozen (held on last valid value), alarm values, limits are not active.
Range: 0–6000 s

4.2 Relay Contacts

See [Relay Contacts](#), p. 78.

4.3 Logger

The instrument is equipped with an internal logger. The logger data can be copied to the SD card.

- 4.3.1 *Log Interval:* Select a convenient log interval.
Range: 1 s, 5 s, 1 min, 5 min, 10 min, 30 min or 1 h.
- 4.3.2 *Clear Logger:* If confirmed with yes, the complete logger data is deleted. A new data series is started.
- 4.3.3 *Eject SD Card:* With this function all logger data are copied to the SD card and the SD card can be removed.



4.4 Display

Process values are displayed on two screens. Toggle screens with the  key. Each screen displays a maximum of three process values.

4.4.1 Screen 1

4.4.1.1 *Row 1*

4.4.1.2 *Row 2*

4.4.1.3 *Row 3*

Possible settings for all rows are:

- ♦ None
- ♦ Cond 1 (cc)
- ♦ Cond 2 (sc)
- ♦ Difference

If “Calculations” set to “yes”:

- ♦ pH
- ♦ Ammonia (depends on the setting in menu
Sensor parameters > Sensor 1 > Temp. comp.)

4.4.2 Screen 2

See screen 1.

5 Installation

5.1 Sensors

5.1.1 Miscellaneous

5.1.1.1 *Calculations:* Select “yes” if the pH value and the alkalizing reagent concentration should be calculated. Subsequently, pH and concentration are available on screen 1 or 2, on the signal outputs and as alarm or limit values.

5.1.1.2 *Meas. unit:* Choose the measuring unit as $\mu\text{S}/\text{cm}$ or $\mu\text{S}/\text{m}$.

5.1.1.3 *Monitoring of Resin:* Select “yes” if consumption of cation exchange resin should be calculated and displayed.

5.1.1.4 *Resin Capacity:* Enter the resin capacity.
Range: 0.5–4.0 eq/l

5.1.1.5 *Volume of Resin:* Enter the volume of the resin bottle.
Range: 0.5–30.0 l

5.1.2 Sensor parameters

5.1.2.x Sensor 1/2

5.1.2.x.1 *Cell Constant:* Enter the cell constant printed on the sensor label.

5.1.2.x.2 *Temp. Corr:* Enter the temperature correction printed on the sensor label.

5.1.2.x.3 *Cable length:* Enter the cable length. If the transmitter and the flow cell are mounted together on one panel, set the cable length to 0.0 m.

5.1.2.x.5 Temp. comp

5.1.2.x.5.1 *Comp.:* Available compensation models:

- ♦ Strong acids (never select strong acids for sensor 1!)
- ♦ Strong bases
- ♦ Ammonia
- ♦ Morpholine
- ♦ Ethanolamines
- ♦ Cyclohexylamine
- ♦ 2-amino-2-methylpropanol
- ♦ 2-diethylaminoethanol
- ♦ Hydrofluoric acid
- ♦ Neutral salts
- ♦ High purity water
- ♦ Coefficient
- ♦ none

Note: If pH and concentration calculations are enabled, only the following compensation models can be selected:

- Sensor 1: “Strong acids”, “Strong bases”, “Ammonia”, “Morpholine”, “Ethanolamines”, “Cyclohexylamine”, “2-amino-2-methylpropanol” and “2-diethylaminoethanol”.
- Sensor 2: “Strong acids”.



5.2 Signal Outputs

Note: The navigation in the menus Signal Output 1 and Signal Output 2 is equal. For reason of simplicity only the menu numbers of Signal Output 1 are used in the following.

- 5.2.1 Signal Output 1:** Assign process value, the current loop range and a function to each signal output.
- 5.2.1.1 **Parameter:** Assign one of the process values to the signal output.
Available values:
- ♦ Conductivity 1 (cc)
 - ♦ Conductivity 2 (sc)
 - ♦ Temperature 1
 - ♦ Temperature 2
 - ♦ Difference
 - ♦ Sample flow
 - ♦ pH
 - ♦ Concentration
- 5.2.1.2 **Current Loop:** Select the current range of the signal output.
Make sure the connected device works with the same current range.
Available ranges: 0–20 mA or 4–20 mA
- 5.2.1.3 **Function:** Define if the signal output is used to transmit a process value or to drive a control unit. Available functions are:
- ♦ Linear, bilinear, logarithmic or hyperbolic for process values.
 - ♦ Control upwards or control downwards for controllers.

As process
values

The process value can be represented in four ways: linear, bilinear, logarithmic or hyperbolic*. See graphs below.



* Hyperbolic scaling can be used as an alternative to logarithmic scaling in special cases. Contact Swan for details on this scaling method.

5.2.1.40 Scaling: Enter beginning and end point (range low and high) of the linear or logarithmic scale. In addition, the midpoint for the bilinear scale.

Parameters Cond. 1 (sc), Cond 2 (cc):

5.2.1.40.1x Range low: 0–3000 μ S

5.2.1.40.2x Range high: 0–3000 μ S

Parameters Temp. 1, Temp. 2:

5.2.1.40.1x Range low: -25 to +270 °C

5.2.1.40.2x Range high: -25 to +270 °C

Parameter Difference

5.2.1.40.16 Range low: 0–3000 μ S

5.2.1.40.26 Range high: 0–3000 μ S

Parameter Sample flow

5.2.1.40.17 Range low: 0–20 l/h

5.2.1.40.27 Range high: 0–20 l/h

Parameter pH

5.2.1.40.18 Range low: 0–14 pH

5.2.1.40.28 Range high: 0–14 pH

Parameter Ammonia

5.2.1.40.19 Range low: 0–500 ppm

5.2.1.40.29 Range high: 0–500 ppm


**As control
 output**

Signal outputs can be used for driving control units. We distinguish different kinds of controls:

- *P-controller*: The controller action is proportional to the deviation from the setpoint. The controller is characterized by the P-Band. In the steady-state, the setpoint will never be reached. The deviation is called steady-state error.
 Parameters: setpoint, P-Band
- *PI-controller*: The combination of a P-controller with an I-controller will minimize the steady-state error. If the reset time is set to zero, the I-controller is switched off.
 Parameters: setpoint, P-Band, reset time.
- *PD-controller*: The combination of a P-controller with a D-controller will minimize the response time to a fast change of the process value. If the derivative time is set to zero, the D-controller is switched off.
 Parameters: setpoint, P-Band, derivative time.
- *PID-controller*: The combination of a P-, an I- and a D-controller allows a proper control of the process.
 Parameters: setpoint, P-Band, reset time, derivative time.

Ziegler-Nichols method for the optimization of a PID controller:

Parameters: Setpoint, P-Band, reset time, derivative time.



A Response to maximum control output $X_p = 1.2/a$

B Tangent on the inflection point $T_n = 2L$

X Time $T_v = L/2$

The point of intersection of the tangent with the respective axis will result in the parameters a and L.

Consult the manual of the control unit for connecting and programming details. Choose control upwards or downwards.

Control upwards or downwards

Setpoint: User-defined process value for the selected parameter.

P-Band: Range below (upwards control) or above (downwards control) the setpoint, within the dosing intensity is reduced from 100% to 0% to reach the setpoint without overshooting.

5.2.1.43 Control Parameters: if Parameters = Cond. 1 (sc)

5.2.1.43.10 Setpoint
Range: 0–3000 µS

5.2.1.43.20 P-Band:
Range: 0–3000 µS

5.2.1.43 Control Parameters: if Parameters = Cond. 2 (cc)

5.2.1.43.11 Setpoint
Range: 0–3000 µS

5.2.1.43.21 P-Band:
Range: 0–3000 µS

5.2.1.43 Control Parameters: if Parameters = Temp. 1

5.2.1.43.13 Setpoint
Range: -25 to +270 °C

5.2.1.43.23 P-Band:
Range: -25 to +270 °C

5.2.1.43 Control Parameters: if Parameters = Temp. 2

5.2.1.43.14 Setpoint
Range: -25 to +270 °C

5.2.1.43.24 P-Band:
Range: -25 to +270 °C

5.2.1.43 Control Parameters: if Parameters = Difference

5.2.1.43.16 Setpoint
Range: 0–3000 µS

5.2.1.43.26 P-Band:
Range: 0–3000 µS

5.2.1.43 Control Parameters: if Parameters = Sample flow

5.2.1.43.17 Setpoint
Range: 0–20 l/h

5.2.1.43.27 P-Band:
Range: 0–20 l/h

- 5.2.1.43 Control Parameters:** if Parameters = pH
- 5.2.1.43.18 Setpoint
Range: 0–14 pH
- 5.2.1.43.28 P-Band:
Range: 0–14 pH
- 5.2.1.43 Control Parameters:** if Parameters = Ammonia
- 5.2.1.43.19 Setpoint
Range: 0–500 ppm
- 5.2.1.43.29 P-Band:
Range: 0–500 ppm
- 5.2.1.43.3 *Reset time:* The reset time is the time till the step response of a single I-controller will reach the same value as it will be suddenly reached by a P-controller.
Range: 0–9'000 sec
- 5.2.1.43.4 *Derivative time:* The derivative time is the time till the ramp response of a single P-controller will reach the same value as it will be suddenly reached by a D-controller.
Range: 0–9'000 sec
- 5.2.1.43.5 *Control timeout:* If a controller action (dosing intensity) is constantly over 90% during a defined period of time and the process value does not come closer to the setpoint, the dosing process will be stopped for safety reasons.
Range: 0–720 min



5.3 Relay Contacts

5.3.1 Alarm Relay: The alarm relay is used as cumulative error indicator. Under normal operating conditions the contact is active.

The contact is inactive at:

- ◆ Power loss
- ◆ Detection of system faults like defective sensors or electronic parts
- ◆ High case temperature
- ◆ Process values out of programmed ranges.

Program alarm levels, hysteresis values and delay times for the following parameters:

- ◆ Cond. 1 (sc)
- ◆ Cond. 2 (cc)
- ◆ pH
- ◆ Ammonia
- ◆ Sample Temp. 1
- ◆ Sample Temp. 2
- ◆ Sample Flow
- ◆ Case Temperature

5.3.1.1 Conductivity

5.3.1.1.1 Cond. 1 (sc)

5.3.1.1.1.1 *Alarm High:* If the measured value rises above the alarm high value, the alarm relay switches and E001 is displayed in the message list.
Range: 0 – 3000 µS

5.3.1.1.1.25 *Alarm Low:* If the measured value falls below the alarm low value, the alarm relay switches and E002 is displayed in the message list.
Range: 0 – 3000 µS

5.3.1.1.1.35 *Hysteresis:* Within the hysteresis range, the alarm relay does not switch. This prevents damage of relays contacts when the measured value fluctuates around the alarm value.
Range: 0 – 3000 µS

5.3.1.1.1.45 *Delay:* Waiting time before the alarm relay becomes inactive after the measured value has risen above or fallen below the programmed alarm value.
Range: 0 – 28'800 s

5.3.1.1.2 Cond. 2 (cc)

5.3.1.1.2.1 *Alarm High:* If the measured value rises above the alarm high value, the alarm relay switches and E003 is displayed in the message list.
Range: 0 – 3000 µS

- 5.3.1.1.2.25 *Alarm Low:* If the measured value falls below the alarm low value, the alarm relay switches and E004 is displayed in the message list.
Range: 0–3000 μ S
- 5.3.1.1.2.35 *Hysteresis:* Within the hysteresis range, the alarm relay does not switch. This prevents damage of relays contacts when the measured value fluctuates around the alarm value.
Range: 0–3000 μ S
- 5.3.1.1.2.45 *Delay:* Waiting time before the alarm relay becomes inactive after the measured value has risen above or fallen below the programmed alarm value.
Range: 0–28'800 s
- 5.3.1.1.4 pH (if Calculations = yes)**
- 5.3.1.1.4.1 *Alarm High:* If the measured value rises above the alarm high value, the alarm relay switches and E033 is displayed in the message list.
Range: 0–14 pH
- 5.3.1.1.4.25 *Alarm Low:* If the measured value falls below the alarm low value, the alarm relay switches and E034 is displayed in the message list.
Range: 0–14 pH
- 5.3.1.1.4.35 *Hysteresis:* Within the hyst. range, the relay does not switch. This prevents damage of relays contacts when the measured value fluctuates around the alarm value.
Range: 0–14 pH
- 5.3.1.1.4.45 *Delay:* Waiting time before the alarm relay becomes inactive after the measured value has risen above or fallen below the programmed alarm value.
Range: 0–28'800 s
- 5.3.1.1.5 Ammonia (if Calculations = yes)**
- 5.3.1.1.5.1 *Alarm High:* If the measured value rises above the alarm high value, the alarm relay switches and E035 is displayed in the message list.
Range: 0–500 ppm
- 5.3.1.1.5.25 *Alarm Low:* If the measured value falls below the alarm low value, the alarm relay switches and E036 is displayed in the message list.
Range: 0–500 ppm
- 5.3.1.1.5.35 *Hysteresis:* Within the hyst. range, the relay does not switch. This prevents damage of relays contacts when the measured value fluctuates around the alarm value.
Range: 0–500 ppm
- 5.3.1.1.5.45 *Delay:* Waiting time before the alarm relay becomes inactive after the measured value has risen above or fallen below the programmed alarm value.
Range: 0–28'800 s

5.3.1.2 Sample Temp.

5.3.1.2.1 Temp. 1

5.3.1.2.1.1 *Alarm High:* If the measured value rises above the alarm high value, the alarm relay switches and E007 is displayed in the message list.
Range: 30–200 °C

5.3.1.2.1.25 *Alarm Low:* If the measured value falls below the alarm low value, the alarm relay switches and E008 is displayed in the message list.
Range: -10 to +20 °C

5.3.1.2.2 Temp. 2

5.3.1.2.2.1 *Alarm High:* If the measured value rises above the alarm high value, the alarm relay switches and E037 is displayed in the message list.
Range: 30–200 °C

5.3.1.2.2.25 *Alarm Low:* If the measured value falls below the alarm low value, the alarm relay switches and E038 is displayed in the message list.
Range: -10 to +20 °C

5.3.1.2 Sample Flow: Define at which sample flow a flow alarm should be issued.

5.3.1.2.1 *Flow Alarm:* Program if the alarm relay should switch if there is a flow alarm. The flow alarm will always be indicated on the display, in the pending error list, saved in the message list and the logger. Available values: Yes or no

***Note:** Sufficient flow is essential for a correct measurement.
We recommend to program yes.*

5.3.1.2.x *Alarm High:* If the measured value rises above the programmed value E009 will be issued.
Range: 10.0–50.0 l/h

5.3.1.2.x *Alarm Low:* If the measured value falls below the programmed value E010 will be issued.
Range: 0.0–9.0 l/h

5.3.1.3 Case Temp.

5.3.1.3.1 *Alarm high:* Set the alarm high value for temperature of electronics housing. If the value rises above the programmed value E013 is issued.
Range: 30–75 °C

5.3.1.3.2 *Alarm low:* Set the alarm low value for temperature of electronics housing. If the value falls below the programmed value E014 is issued.
Range: -10 to +20 °C

5.3.x Relay 1 and 2: The function of relay contacts 1 or 2 is defined by the user.

Note: The navigation in the menus Relay 1 and Relay 2 is equal. For reason of simplicity only the menu numbers of Relay 1 are used in the following.

- 1 First select the functions as:
 - Limit upper/lower,
 - Control upwards/downwards,
 - Timer,
 - Fieldbus.
- 2 Then enter the necessary data depending on the selected function. The same values can also be entered in menu 4.2.

5.3.2.1 Function = Limit upper/lower

If the relays are used as upper or lower limit switches, program the following:

5.3.2.20 *Parameter:* select a process value.

5.3.2.300 *Setpoint:* If the measured value rises above respectively falls below the set-point, the relay is activated.

Parameter	Range
Cond. 1 (sc)	0.000–3000 µS
Cond. 2 (cc)	0.000–3000 µS
Temp. 1	-25 to +270 °C
Temp. 2	-25 to +270 °C
Difference	0.000–3000 µS
Sample flow	0–20 l/h
pH	0–14 pH
Ammonia	0–500 ppm

5.3.2.400 *Hysteresis:* within the hysteresis range, the relay does not switch. This prevents damage of relay contacts when the measured value fluctuates around the alarm value.

Parameter	Range
Cond. 1 (sc)	0.000–3000 µS
Cond. 2 (cc)	0.000–3000 µS
Temp. 1	0–100 °C
Temp. 2	0–100 °C
Difference	0–3000 µS
Sample flow	0–20 l/h

Parameter	Range
pH	0 – 14 pH
Ammonia	0 –500 ppm

5.3.2.50 *Delay:* Waiting time before the relay becomes active after the measured value has risen above or fallen below the programmed value. Range. 0–600 s

5.3.2.1 Function = Control upwards/downwards

If the relays are used to control dosing units, program the following.

5.3.2.22 *Parameter:* Choose one of the following process values.

- ◆ Cond. 1 (sc)
- ◆ Cond. 2 (cc)
- ◆ Temp. 1
- ◆ Temp. 2
- ◆ Difference
- ◆ Sample Flow
- ◆ pH
- ◆ Ammonia

5.3.2.32 Settings: Choose the respective actuator:

- ◆ Time proportional
- ◆ Frequency

5.3.2.32.1 Actuator = Time proportional

Dosing is controlled by the operating time.

5.3.2.32.20 *Cycle time:* Duration of one control cycle (on/off change). Range: 0–600 s.

5.3.2.32.30 *Response time:* Minimal time the metering device needs to react. Range: 0–240 s.

5.3.2.32.4 Control Parameters

Range for each parameter same as 5.2.1.43.

5.3.2.32.1 Actuator = Frequency

Dosing is controlled by the repetition speed of dosing shots.

5.3.2.32.21 *Pulse frequency:* Max. pulses per minute the device is able to respond to. Range: 20–300/min.

5.3.2.32.31 Control Parameters

Range for each parameter same as 5.2.1.43.

5.3.2.1 Function = Timer

The relay will be activated repetitively depending on the programmed time scheme.

- p>5.3.2.24
- Mode:*
- Operating mode (interval, daily, weekly).
p>5.3.2.24
- Interval*
- p>5.3.2.340
- Interval:*
- The interval can be programmed within a range of 1–1440 min.
p>5.3.2.44
- Run Time:*
- Enter the time the relay stays active.
-
- Range: 5–32400 s.
p>5.3.2.54
- Delay:*
- during run time plus the delay time the signal and control outputs are held in the operating mode programmed below.
-
- Range: 0–6000 s.
p>5.3.2.6
- Signal Outputs:*
- Select operating mode of the signal output:
p>
- Cont.:*
- Signal outputs continue to issue the measured value.
p>
- Hold:*
- Signal outputs hold the last valid measured value. Errors, except fatal errors, are not issued.
p>
- Off:*
- Signal outputs are switched off (set to 0 or 4 mA). Errors, except fatal errors, are not issued.
p>5.3.2.7
- Output/Control:*
- Select operating mode of the controller output:
p>
- Cont.:*
- Controller continues normally.
p>
- Hold:*
- Controller continues based on the last valid value.
p>
- Off:*
- Controller is switched off.
p>5.3.2.24
- daily*
- p>The relay contact can be activated daily, at any time of a day.
p>5.3.2.341
- Start time:*
- Time of day at which the relay is activated.
-
- Range: 00:00:00–23:59:59
p>5.3.2.44
- Run Time:*
- see Interval.
p>5.3.2.54
- Delay:*
- see Interval.
p>5.3.2.6
- Signal Outputs:*
- see Interval.
p>5.3.2.7
- Output/Control:*
- see Interval.
p>5.3.2.24
- weekly*
- p>The relay contact can be activated on one or several days of a week.
p>
- 5.3.2.342 Calendar**
- p>5.3.2.342.1
- Start time:*
- The programmed start time is valid for each of the programmed days.
-
- Range: 00:00:00–23:59:59
p>5.3.2.342.2
- Monday:*
- Possible settings, on or off.
-
- to
p>5.3.2.342.8
- Sunday:*
- Possible settings, on or off.
p>5.3.2.44
- Run Time:*
- see Interval.

- 5.3.2.54 *Delay*: see Interval.
- 5.3.2.6 *Signal Outputs*: see Interval.
- 5.3.2.7 *Output/Control*: see Interval.
- 5.3.2.1 **Function = Fieldbus**
 The relay is switched via Profibus or Modbus.
- 5.3.4 Input**: The functions of the relays and signal outputs can be defined depending on the position of the input contact, i.e. no function, closed or open.
- 5.3.4.1 *Active*: Define when the input should be active:
- No*: Input is never active.
- When closed*: Input is active when the input relay is closed.
- When open*: Input is active when the input relay is open.
- 5.3.4.2 *Signal Outputs*: Select the operation mode of the signal outputs when the input is active:
- Continuous*: Signal outputs continue to issue the measured value.
- Hold*: Signal outputs hold the last valid measured value. Errors, except fatal errors, are not issued.
- Off*: Sets the signal outputs to 0 or 4 mA. Errors, except fatal errors, are not issued.
- 5.3.4.3 *Output/Control*: (relay or signal output):
- Continuous*: Controller continues normally.
- Hold*: Controller continues based on the last valid value.
- Off*: Controller is switched off.
- 5.3.4.4 *Fault*:
- No*: No message is issued in pending error list and the alarm relay does not switch when input is active. Message E024 is stored in the message list.
- Yes*: Message E024 is issued and stored in the message list. The alarm relay switches when input is active.
- 5.3.4.5 *Delay*: Time that the instrument waits after the input is deactivated, before returning to normal operation.
 Range: 0–6'000 s

5.4 Miscellaneous

- 5.4.1 *Language*: Set the desired language.
Available settings: German, English, French, Spanish.
- 5.4.2 *Set defaults*: Reset the instrument to factory default values in three different ways:
- ♦ **Calibration**: Sets calibration values back to default. All other values are kept in memory.
 - ♦ **In parts**: Communication parameters are kept in memory. All other values are set back to default values.
 - ♦ **Completely**: Sets back all values including communication parameters.
- 5.4.3 *Load Firmware*: Firmware updates should be done by instructed service personnel only.
- 5.4.4 **Password**: Select a password different from 0000 to prevent unauthorized access to the menus "Messages", "Maintenance", "Operation" and "Installation".
Each menu can be protected by a different password.
If you forgot the passwords, contact the closest Swan representative.
- 5.4.5 *Sample ID*: Identify the process value with any meaningful text, such as KKS number.

5.5 Interface

Select one of the following communication protocols.

5.5.1 *Protocol*: Profibus

- 5.5.20 Device address: Range: 0–126
- 5.5.30 ID no.: Range: Analyzer; Manufacturer; Multivariable
- 5.5.40 Local operation: Range: Enabled, Disabled

5.5.1 *Protocol*: Modbus RTU

- 5.5.21 Device address: Range: 0–126
- 5.5.31 Baud rate: Range: 1 200–115 200 Baud
- 5.5.41 Parity: Range: none, even, odd

5.5.1 *Protocol*: HART

- Device address: Range: 0–63

10. Material Safety Data sheets

10.1. Swan Cation Exchange Resin

Product name: Cation Exchange Resin
Catalogue number: A-82.841.030

**Download
MSDS**

The current Material Safety Data Sheets (MSDS) for the above listed Reagents are available for downloading at www.swan.ch.

11. Default Values

Operation:

Sensors:	Filter Time Const.:	20 s
	Hold after Cal.:	0 s
Relay Contacts	Alarm Relay	same as in Installation
	Relay 1/2	same as in Installation
	Input	same as in Installation
Logger:	Logger Interval:	30 min
	Clear Logger:	no
Display	Screen 1 and 2; Row 1:	Cond 1(sc)
	Screen 1 and 2; Row 2:	Cond 1(cc)
	Screen 1 and 2; Row 3:	None

Installation:

Sensors	Miscellaneous; Calculations:	no
	Miscellaneous; Meas. unit:	$\mu\text{S/cm}$
	Miscellaneous; Monitoring of Resin:	no
	Miscellaneous; Resin Capacity:	1.8
	Miscellaneous; Volume of Resin:	1.0 l
	Sensor Parameters; Sensor 1/2; Cell Constant:	0.0415 cm^{-1}
	Sensor Parameters; Sensor 1/2; Temp. corr.:	$0.00 \text{ }^{\circ}\text{C}$
	Sensor Parameters; Sensor 1/2; Cable length	0.0 m
	Sensor Parameters; Sensor 1; Temp. comp.; Comp:	Ammonia
	Sensor Parameters; Sensor 2; Temp. comp.; Comp:	Strong Acids
Signal Output 1	Parameter:	Cond.1(sc)
	Current loop:	4 –20 mA
	Function:	linear
	Scaling: Range low:	$0.000 \mu\text{S}$
	Scaling: Range high:	$1000.00 \mu\text{S}$
Signal Output 2	Parameter:	Cond.2(sc)
	Current loop:	4 –20 mA
	Function:	linear
	Scaling: Range low:	$0.000 \mu\text{S}$
	Scaling: Range high:	$1000.00 \mu\text{S}$
Alarm Relay:	Conductivity; Cond. 1 (sc), Cond. 2 (cc):	
	Alarm high:	$3000.00 \mu\text{S}$
	Alarm low:	$0.000 \mu\text{S}$
	Hysteresis:	$10.0 \mu\text{S}$
	Delay:	5 s

Sample Flow:
Flow Alarm.....yes
Alarm high: 16.0 l/h
Alarm low: 5.0 l/h
Sample Temp (Temp. 1, Temp. 2):
Alarm High: 160 °C
Alarm Low: 0 °C
Case Temp. high: 65 °C
Case Temp. low: 0 °C
Relay 1/2 Function: limit upper
Parameter: Cond. 1(sc)
Setpoint: 1000 µS
Hysteresis: 10.0 µS
Delay: 30 s

If Function = Control upw. or dnw:

Parameter: Cond 1(sc)
Settings: Actuator: Frequency
Settings: Pulse Frequency: 120/min.
Settings: Control Parameters: Setpoint: 1000 µS
Settings: Control Parameters: P-band: 10 µS
Settings: Control Parameters: Reset time: 0 s
Settings: Control Parameters: Derivative Time: 0 s
Settings: Control Parameters: Control Timeout: 0 min
Settings: Actuator: Time proportional
Cycle time: 60 s
Response time: 10 s

If Function = Timer:

Mode: Interval
Interval: 1 min
Mode: daily
Start time: 00.00.00
Mode: weekly
Calendar; Start time: 00.00.00
Calendar; Monday to Sunday: Off
Run time: 10 s
Delay: 5 s
Signal output: cont
Output/Control: cont

Input:	Active	when closed
	Signal Outputs	hold
	Output/Control	off
	Fault.....	no
	Delay.....	10 s
Miscellaneous	Language:.....	English
	Set default:.....	no
	Load firmware:	no
	Password:	for all modes 0000
	Sample ID:	- - - - -

This image shows a full page of white paper with horizontal blue ruling lines. The lines are evenly spaced and run across the width of the page. There is no handwriting or other markings on the paper.

This image shows a full page of white paper with horizontal blue ruling lines. The lines are evenly spaced and run across the width of the page. There is no handwriting or other markings on the paper.

Swan Products - Analytical Instruments for:



Swan is represented worldwide by subsidiary companies and distributors and cooperates with independent representatives all over the world. For contact information, please scan the QR code.

Swan Analytical Instruments · CH-8340 Hinwil
www.swan.ch · swan@swan.ch



MADE IN
SWITZERLAND

